NAVMAN WIRELESS

M-Nav 760

User Manual

GPS TRACKING AND FLEET MANAGEMENT SOLUTIONS

Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Copyright

© Copyright 2010 Navman Wireless Holdings LP. Navman Wireless is a registered trademark of Navman Wireless Holdings LP. All rights reserved.

All other trademarks and registrations are the property of their respective owners.

Contents

1 Introduction 5
- 1.1 Important Safety Information 5
- 1.2 Disclaimer 5
- 1.3 Glossary of Terms 6

2 The M-Nav 760 7
- 2.1 Box Contents 7
- 2.2 M-Nav 760 Parts 8
- 2.3 M-Nav 760 Specifications 9

3 Install the M-Nav 760 in a Vehicle 10
- 3.1 Assemble the Docking Cradle 10
- 3.2 Windscreen Installation 10
- 3.3 Add the M-Nav 760 to the Docking Cradle 11

4 Get Started 12
- 4.1 Language and Warning Screens 12
- 4.2 Driver Logon & Status 13
- 4.3 Vehicle Inspection 13
- 4.4 Check the GPS Status 14
- 4.5 Check the Qube Tracking Device Status 15
- 4.6 Driver Logoff 16
- 4.7 Shut Down 16

5 Messages. 17
- 5.1 Types of Message 17
- 5.2 New Messages 17
- 5.3 Read a Received Message 19
- 5.4 Reply with a Canned Template or Reply Form 20
- 5.5 Use a Reply Form 21
- 5.6 View a Reply or a Sent Message 21
- 5.7 Create a New Message or Free Text Reply 23
- 5.8 Show a Message Location 24
- 5.9 Go to a Message Location 24
- 5.10 Delete a Message 25

6 Phone. 26
- 6.1 Check Bluetooth Status of the M-Nav 760 26
- 6.2 Switch Bluetooth ON 26
- 6.3 Pair a Mobile Phone 27
- 6.4 Change the Active Mobile Phone 29
- 6.5 Import a Phone Book 30
- 6.6 Make a Speaker Phone Call from Dial Pad 31
- 6.7 Make a Speaker Phone Call from Phone Book 32
- 6.8 Delete a Mobile Phone 33

7 Navigation Basics 34
7.1 Display & Move the Map 34
7.2 Map Icons 34
7.3 Navigation Icons 35
7.4 Mute or Set the Navigation Volume 36
7.5 Night-Time Navigation 37
7.6 How to Enter Data & Remove Errors 38

8 Find and Go to a Location 39
8.1 Find a Street Address 39
8.2 Find a Postal Code 40
8.3 Find Other Types of Location 41
8.4 Find a POI 42
8.5 Navigate to a Destination from Your Location 43
8.6 Set a Location as Home 44
8.7 Set a Location as a Favourite Place 45

9 Plan a Route 46
9.1 Plan a Route from Any Location 46
9.2 Add a Location as a Via Point 47
9.3 Show / Add Places Along the Route 48
9.4 Optimise / Change the Order of the Via Points 49
9.5 Save a Route 49
9.6 Add a Detour to Avoid an Area 50
9.7 Use a Saved Route 50
9.8 Delete a Saved Route 51
9.9 Delete a Route 51

10 Route Information 52
10.1 Show an Overview of this Route 52
10.2 Demonstrate this Route 52
10.3 Show Total Time & Distance 53
10.4 Show all Manoeuvres on the Route 53

11 Set Your Preferences 54
11.1 Set Route Type & Vehicle Type 54
11.2 Set Truck Attributes 55
11.3 Set Road Types to Avoid 56
11.4 Set Road Types to Exclude 57
11.5 Set Distance Units 58
11.6 Set Date / Time Formats 58
11.7 Set Geographic / Custom Time Zone 59
11.8 Set Language 60
11.9 Set the Choose Language at Startup Option 61
11.10 Restore Factory Default Settings 62

1 Introduction

Thank you for purchasing the Navman Wireless M-Nav 760 messaging and navigation device. We hope you enjoy using it. It has been carefully designed so it is easy to install, setup, and use.

You can:

- use the navigation option to search for locations such as a street address, a postal code, or a city centre
- set a location as the start point, a via point, or the destination
- have the M-Nav 760 calculate the route then guide you along it with clear visual and verbal instructions
- check for places and points of interest such as fuel stops, nearby or along your route,
- add stops (via points) to your route
- use the phone option to pair the M-Nav 760 with a Bluetooth-enabled mobile phone, then make and receive hands-free phone calls using the M-Nav 760 as the speaker
- use the message option to receive messages from, and send messages to, your fleet administrator
- navigate directly to a location specified in a message from your fleet administrator
- use the setup option to customise the M-Nav 760 to suit your own preferences.

1.1 Important Safety Information

Do NOT mount the M-Nav 760 where it obstructs the driver's view or may distract the driver.

DO NOT mount the M-Nav 760 where it may interfere with the safe operation of the vehicle or the deployment of airbags or other safety equipment. Consult the vehicle manual to ensure the mounting location is safe, if necessary.

Do NOT enter navigation data or other information into the M-Nav 760 while you are driving.

Comply with these safety instructions at all times. Failure to comply with these safety instructions may lead to accidents, personal injury including death, property damage or violation of the law.

1.2 Disclaimer

Navman Wireless disclaims all liability for installation and use of this product in a way that contributes to injuries, death, property damage or violation of the law.

The user of this product is solely responsible for observing safe driving practices and for all use of this device. It is the user's responsibility to operate the M-Nav 760 in accordance with the law.

This M-Nav 760 provides route information for guidance only. Accordingly it is your sole responsibility to consider the height, weight, length or Hazmat classification of your vehicle and to ensure that it is legally and physically able to travel over routes that may include narrow, twisting or steep roads; weak, narrow or low bridges; tunnels or other obstacles on the route determined by this M-Nav 760.

The M-Nav 760 device provides an interface to a Bluetooth-enabled mobile phone. Navman Wireless disclaims all responsibility for any Bluetooth-enabled mobile phone problems that result

from faults with the mobile phone including but not limited to lost connections, text messages, and contact details.

This manual represents the M-Nav 760 at the time of printing. Navman Wireless reserves the right to make changes to specifications without notice.

1.3 Glossary of Terms

Common terms used in this manual and on the M-Nav 760 include:

GPS	The GPS is a network of satellites that orbit the Earth at about 19,300 kms (12,000 miles) and transmit accurate time and position information worldwide. The GPS receiver in your M-Nav 760 picks up signals from any satellites in view and uses the information to determine your location, accurate to within 5 m (15 ft). Usually, only three signals are needed to provide a latitude and longitude position (GPS fix) for vehicle navigation systems.
POI	Point of Interest. This is a useful resource along or nearby the route, such as a fuel location or a post office. You can add a POI to your route as a via point.
Via Point	A specific location that you want to visit along the route. A via point can be any location that you specify, such as a customer site, or a POI.
Destination	The next via point along your route.
Final Destination	The final via point along your route. It is always marked with a chequered flag.
Trip	The complete list of via points that you specify; including the start location, the final destination, and any via points between.
Route	When you have defined all the via points in your trip, the M-Nav 760 will calculate the best route automatically after it obtains a GPS fix. Your route shows the path to drive. Only one route can be shown on the map at a time.

2 The M-Nav 760

2.1 Box Contents

The M-Nav 760 is supplied with a suction mount designed for installation on a vehicle windscreen. Check that you have ALL of these items before you start the installation. Contact your supplier if anything is missing.

M-Nav 760 device

Silicone case

Suction mount

Cradle

PND cable

Alcohol swab

2.2 M-Nav 760 Parts

Familiarise yourself with the parts of your M-Nav 760 before starting the installation.

	Component	Description
1	Mini-USB port	External connection port. Not used in standard vehicle installations.
2	Serial connection	When the M-Nav 760 is in its cradle, this serial connection provides external power and data from the Qube tracking device.
3	Micro-SD card	Contains the maps for the navigation feature.
4	Microphone	Used for Bluetooth voice calls.
5	Jack point	Headset connection point (optional).
6	LED	Power indicator light. This will be ON when external power is applied to the M-Nav 760.
7	Standby button	Press to toggle the M-Nav 760 between operating and standby state. When the M-Nav 760 is in standby state and the screen is blank, just press the standby button to re-display the most recent screen. (**Note:** if the M-Nav 760 internal battery has discharged the splash screen will be displayed instead).
8	Internal GPS antenna	Approximate position of the internal GPS antenna that is built into the M-Nav 760 and is not visible to view.
9	Lower Cradle Clips	Used for docking M-Nav 760 in the cradle.
10	ON/OFF switch	Switch the internal battery ON or OFF. Usually switched ON. Also used to reset the M-Nav 760 in the event of an upgrade.
11	Speaker	Provides system sounds and navigational voice prompts.
12	Back Cradle Clips	Used for docking M-Nav 760 in the cradle.
13	Screen	Displays menus, maps and messages.

2.3 M-Nav 760 Specifications

Display unit

- 117 x 78 x 18 mm, landscape form factor
- 140 g
- Polished texture, suction cup mounting for vehicle

Screen

- 109 mm wide TFT LCD touch screen with high colour
- Resolution 480 x 272 x 16 bits (WQVGA)

Temperature

- Operating range: -10 to +60°C (Storage range: -20 to +70°C)

Humidity

- Operating range: 20~80% (Storage range: 0~90%)

Voltage

- Suitable for 12 and 24 V systems

3 Install the M-Nav 760 in a Vehicle

Note: These installation instructions assume that the Qube tracking device is already installed in the vehicle and that the cable and mini-USB have been fed through the dashboard, ready for connection to the M-Nav 760.

When you have assembled the docking cradle, use the suction cup to attach the M-Nav 760 to the vehicle windscreen.

3.1 Assemble the Docking Cradle

You must connect the bracket to the cradle as follows:

1. Identify the two holes in the cradle and the two prongs on the bracket.
2. Slide the holes on the cradle down over the prongs on the bracket, as far as possible.

The docking cradle is assembled. You can change the tilt angle and the viewing angle with the two adjustment knobs.



3.2 Windscreen Installation

Note: Some windscreens contain areas of tinted glass that may interfere with the GPS signal. Do not mount the M-Nav 760 in these areas.

Read the Important Safety Information in section 1.1.

Decide where to locate the suction mount on the windscreen. Use the alcohol swab to thoroughly clean that area of the windscreen, then dry the area with a soft, lint-free cloth.

Press the suction cup firmly against the windscreen for 3 seconds.

Push the lever down to vacuum-seal the suction cup to the windscreen.

Now you are ready to add the M-Nav 760 to the docking cradle. See section 3.3.

3.3 Add the M-Nav 760 to the Docking Cradle

IMPORTANT: *Check the M-NAV 760 internal battery switch is ON before you add the M-Nav 760 to the docking cradle. You should not need to touch this switch again after it has been switched ON.*

Insert the mini-USB (attached to the cable already fed through the dashboard from the Qube tracking device) into the mini-USB port at the back of the docking cradle.

Put the bottom of the M-Nav 760 into the docking cradle, and then push the M-Nav 760 gently back until it snaps into place with an audible click.

IMPORTANT: *The M-Nav 760 must be in the docking cradle and connected to the Qube tracking device in order for you to report your driver status, send and receive messages and otherwise communicate with your fleet administrator through the OnlineAVL2 application.*

The start up screen will display automatically. See section 4.

Use the adjustment knobs on the docking cradle to change the viewing angle and the tilt angle, if necessary, to give a comfortable viewing position.

If you are leaving the vehicle for a while, we recommend that you remove the M-Nav 760 from the docking cradle and store it in a safe place.

Note: The M-Nav 760 will charge only when connected to a Qube in a standard vehicle installation or AC adaptor supply. It will **not** charge when connected to a standard USB connection through a PC or similar.

4 Get Started

4.1 Language and Warning Screens

Note: The following sequence of screens will appear the FIRST time that you use your M-Nav 760, OR whenever the internal battery in the M-Nav 760 has gone flat (this can happen if you have not used your M-Nav 760 for several days). Otherwise, your M-Nav 760 will re-display the last screen that you used.

The loading bar will appear on the screen while the software is loading into your M-Nav 760.

If this 'Language' screen appears, just touch the language you want to use, then touch **Accept**.

Note: You can configure your M-Nav to choose this language automatically at start up (see section 11.9).

Note: The country map is loaded automatically and is independent of the language that you select here.



The 'Warning' screen is displayed automatically.

Touch the down-arrow to scroll down and read all of the warning.

If you accept the warnings, touch **Accept**.


Warning
You must secure and use the M-Nav 750 so as not to cause personal injury or property damage, or obstruct your view or interfere with vehicle safety equipment. Do not operate the M-Nav 750 while driving. You are solely responsible for observing safe driving practices at all times and for installation and all use of the M-Nav 750.
You are solely responsible for ensuring that your vehicle can travel legally and safely over the routes determined by the M-Nav 750 and under the conditions existing at the time of travel.
Accept

If the 'Main Menu' is displayed, your M-Nav 760 is ready to use. The 'Main Menu' may have four icons, as shown here, or six icons, depending on the features that have been enabled by your fleet administrator.

Just touch an icon to select that option.

Note: If a different screen is displayed instead of the 'Main Menu', see the next section.

4.2 Driver Logon & Status

Note: These screens appear only if your fleet administrator has setup the Driver Logon and Driver Status functions in the OnlineAVL2 application. If so, you cannot use the M-Nav 760 until you enter these details.

IMPORTANT: *The M-Nav 760 must be in the docking cradle and connected to the Qube tracking device in order for you to report your driver status to your fleet administrator through the OnlineAVL2 application.*

If the 'Driver Logon' screen is displayed, use the onscreen keypad to enter your Driver Pin (Personal identification number) then touch **Logon**.

If the 'Select Driver Logon Status' screen appears, touch the description that best describes your current status (e.g. **Other Work**).

Note: Driving is the default Driver Logon Status. Just touch this if it is your current status.



4.3 Vehicle Inspection

Note: The ''Vehicle Inspection' option may not be available in your market. Contact your supplier for more information. If these screens appear you cannot use the M-Nav 760 until you enter these details.

If the 'Vehicle Inspection' screen appears, you must inspect your vehicle, and then touch **Accept**.


Vehicle Inspection
I have carried out my vehicle inspection in accordance with Company Policy.
Press Accept to Confirm.
Accept

The 'Select Vehicle Inspection Result' screen is displayed.

Touch the appropriate result. The M-Nav 760 automatically creates and sends a text message to your fleet administrator to advise the result of your vehicle inspection.



When the 'Main Menu' is displayed your M-Nav 760 is ready to use. Just touch an icon to select that option.

When you have finished using the M-Nav 760, remember to Logoff. See section 4.6.

4.4 Check the GPS Status

Your M-Nav 760 has an internal GPS (Global Positioning System) antenna so that you can always receive a GPS signal, find your current location and use the M-Nav 760 for navigation. For best operation, ensure that your M-Nav 760 is positioned where it has a good view of the sky.

To check the status of the GPS signal at any time, display the 'Main Menu'. Touch **Nav**.

The map is displayed. This example shows a default map view (specific to your region) which includes the horizon. The GPS signal reception icons are shown in the centre of the menu bar at the bottom of the map. These show whether a GPS signal is being received and, if so, the strength of the GPS signal.

If there is no GPS signal, drive to another location or wait a few minutes for the GPS satellites to change their position.

GPS (No green bars) No GPS signal.

GPS (One green bar) Weak GPS signal.

GPS (Two green bars) Medium GPS signal.

GPS (Three green bars) Strong GPS signal.

Note: If the GPS signal is often weak or absent, try re-positioning the M-Nav 760 in your vehicle so that it has a better view of the sky. (GPS signal reception can be affected by the mounting position as well as urban factors such as high-rise buildings.)

To see more information about the GPS status, just touch a blank area anywhere in the menu bar at the bottom of the map.

An advanced GPS status screen is displayed with detailed information, similar to this example.



Note: To exit from the Navigation option at any time, touch **Menu** then **Main Menu**.

4.5 Check the Qube Tracking Device Status

Your M-Nav 760 is connected to a Qube tracking device that communicates information about your vehicle to the OnlineAVL2 application.

The Qube tracking device also enables you and your fleet administrator to send and receive messages to each other (see section 5).

To check the status of the Qube tracking device at any time, display the 'Main Menu'.

Check the colour of the Qube tracking device icon shown in the top right corner of the screen. The colour of the icon shows the communication status:

(Green) Contact has been established with the OnlineAVL2 application. You can send and receive messages.

(Blue) The Qube tracking device is trying to make contact with the OnlineAVL2 application.

(Red) Contact is not established with the OnlineAVL2 application. You cannot receive messages. If you try to send messages then they will be queued for sending once a connection is established.

4.6 Driver Logoff

If you had to enter your Driver PIN and your work status details (as described in section 4.2) before you could use the M-Nav 760, you must use Logoff when you have finished work.

Note: These screens appear only if your fleet administrator has setup the Driver Logon and Driver Status functions in the OnlineAVL2 application.

To log off, display the 'Main Menu'.

Touch **Logoff**.

When the 'Select Driver Logoff Status' screen appears, touch the description that best describes your current status (e.g. **Rest Break**).



You are logged out automatically and the 'Driver Logon' screen is displayed.

4.7 Shut Down

One minute after you have turned off the ignition, the 'Display Turning Off!' message appears.

The screen turns blank after a 30 second countdown.

Touch the screen if you want to continue using the M-Nav 760 (e.g. to plan a route in advance).

You can continue to use the M-Nav 760 until you see another message warning you that the Qube tracking device is turning off to save power.

5 Messages

IMPORTANT: The M-Nav 760 must be in the docking cradle and connected to the Qube tracking device in order for you to send and receive messages and otherwise communicate with your fleet administrator through the OnlineAVL2 application.

The M-Nav 760 can store a maximum of 500 incoming messages and 250 outgoing messages. If you exceed the limit for incoming messages, the oldest message will be deleted automatically when a new message is received.

5.1 Types of Message

The Message option enables you and your fleet administrator to communicate with each other. There are three types of message:

- **Information messages.** A unique message from fleet administrator; e.g. 'Friday meeting has been changed to 1000 in Room 9' or a unique message that you send; e.g. 'Sorry, can't attend, working at customer site all day'.
- **Form messages.** Your fleet administrator can use a form message to quickly enter and send information to you in a standard format. Each form message contains preset fields; e.g. Job number. Your fleet administrator may also set up reply forms for you to use.
- **Route-To messages.** A message from your fleet administrator with an embedded GPS location you can use to navigate to an address; e.g. '55 Keele Rd, Keele, Newcastle – customer Anna Thompson, cold water coming out of the hot water tap in the kitchen'. This message contains the destination address in the first line of the message so that the M-Nav 760 can navigate you to that address automatically. (A form message can also be set up as a Route-To message.)

5.2 New Messages

When a new message arrives, the New Message popup box is displayed on the current screen and a friendly alert sounds. Touch:

- **Read** to display the new message immediately
- **Cancel** to store the message in your Message List to read it later, when it is safe or convenient

Examples of the three message types are shown below.

This example shows an **information** message. Touch:

- **Back** to close the message without sending a reply
- **Reply** (see section 5.4)
- **Delete** (see section 5.10)



This example shows a **Route-To** message. Route-To messages have two extra option buttons:

- **Go** to exit from the Message option and navigate to the new location (see section 5.9)
- **Show** to exit from the Message option and display the new location on the map (see section 5.8)

Note: If you want to reply to the message, do this first, BEFORE you touch **Go** or **Show**.



This example shows a **form** message that is also a Route-To message. If you cannot see all of the form message, move the scroll bar. Touch:

- **Back** to close the form message without sending a reply
- **Reply** then see section 5.5. (If the form message does not require a reply, the **Reply** button is not shown)

Note: If the form message does not contain a Route-To address, the **Go** and **Show** buttons are not shown.

5.3 Read a Received Message

A received message can be an unread message, or an old message that you have read but not deleted.

Note: Form messages may be deleted automatically after you have read and replied to them, if this feature has been enabled by your fleet administrator.

To read a received message at any time, display the 'Main Menu'.

The number of unread stored messages is shown in the top left corner of the screen. In this example there are 3 unread messages.

Touch **Messages**.

The 'Received Messages' screen lists all your received messages. The most recent message is at top of the list, with the time that it was received by your M-Nav 760.



Touch the up-arrow or down-arrow to move up or down the message list, if necessary.

Touch a received message that you want to read it. It is displayed immediately, along with any previous replies. If you cannot see all of it, move the scroll bar on the far right hand side of the screen.

The following icons show the type of received message and its status:

New unread information or Route-To message.

New unread form message or Route-To form message.

Information or Route-To message has been read.

Form message or Route-To form message has been read.

5.4 Reply with a Canned Template or Reply Form

Note: This section assumes that the information or Route-To message you want to reply to is already displayed. Any previous replies to that message are also displayed in sequence (up to a maximum of 30 replies).

Touch **Reply**.



The 'Canned Templates' screen is displayed.



Canned templates are pre-set replies that can save you time. They show common replies such as 'Yes' and 'No'.

The canned templates may contain one or more reply forms. (Reply forms have a different icon. In this example, 'Answer' is a reply form.)

If you:

- want to reply using a canned template, touch the one that you want to use; e.g. **Yes**, then read the rest of this section
- want to reply using a reply form, touch the one that you want to use; e.g. **Answer**, then see section 5.5
- don't want to use a canned template or reply form, see section 5.7.

The canned template reply is displayed on the screen. Touch:



- **Send** to send the reply immediately. A beep sounds when the reply is sent and the message status icon is updated
- (white arrow on green background) to return to the 'Canned Templates' screen without sending the reply.

Note: You can reply more than once. Just touch the message to re-display it and show any previous replies.

Some canned templates may contain editable text so that you can save time by entering only the relevant details.

For example, if you select the 'Arrive in __ mins' canned template, the blue cursor and the line show where you can enter the estimated number of minutes before you arrive at the destination; e.g. 045.



Note: The M-Nav 760 can hold a maximum of 100 canned messages.

5.5 Use a Reply Form

Note: This section assumes that the reply form is already displayed.

Some relevant details may have been entered automatically (in this example, the Job Number is already entered).

You MUST enter information into each white box. Just touch a white box to select it.

In this example, the onscreen keyboard will be displayed when you touch the white box so that you can type a reply.



Use the onscreen keys to type a reply in this part of the form (see section 5.7 if you need more information about the onscreen keyboard).

Note: To enter numbers, just touch **123** to toggle to the numeric keyboard. Numbers are added from the right-hand side, like a calculator.

Touch **OK**.


Visited customer and left a quote. Also suggested running pipe to garden shed at the same time.
q w e r t y u i o p
a s d f g h j k l
z x c v b n m
alt
123
OK

The information is entered into the white box.

If necessary, touch the scroll bar or the down-arrow to display the rest of the reply form.

Note: Some white boxes may require you to enter a date or a time. If you are entering a time and your M-Nav 760 uses a 12 hour clock, you must touch AM or PM then confirm your choice by touching any numeric key.

2
Reply Job Details
Assessment
Visited customer and left a quote. Also suggested running pipe to garden shed at the same time.
Back
Send

Some white boxes may have a drop-down arrow that you can touch to show a list of reply options.

Use the up-arrow and down-arrow to scroll through these reply options if necessary, then touch one to select it.

When you have entered information into ALL of the white areas, touch Send to send your reply immediately.



Your reply is stored in your 'New Messages Sent to Office' list (see section 5.6).

Note: Your reply may be deleted automatically after you send it, if this feature has been enabled by your fleet administrator.

5.6 View a Reply or a Sent Message

Display the 'Main Menu'.

Touch **Messages**.

The 'Received Messages' screen lists all your stored messages and form messages.

Touch **Sent**.



The 'New Messages Sent to Office' screen lists all your replies. The most recent reply is at the top of the list, with the time that it was sent.

Touch a reply to view it again. It will be displayed immediately.

Note: Form message replies may be deleted automatically after you have sent them and not stored, if this feature has been enabled by your fleet administrator.



Message read and reply sent. (The M-Nav 760 will display a maximum of 30 replies to any stored message.)

Form message read and reply sent.

5.7 Create a New Message or Free Text Reply

If you want to create a new message, display the 'Received Messages' screen (see section 5.3) then touch **New**.

If you want to create your own reply to an information or Route-To message that is already displayed on the M-Nav 760, touch **Reply**.


1
Message 2 of 5
Message received at 05:35 PM on 04/04/09
Chris, your timesheet must be in before noon tomorrow. If I'm not here please leave it with Maria. Thanks, Anna.
Back
Reply
Delete

Note: You can reply to a message more than once. Just touch the message to display it again, with any previous replies.

The 'Canned Templates' screen is displayed.

Touch **Free Text**.



The free text screen onscreen keyboard is displayed.

Type your message using the onscreen keys. Touch:

- **abc** or **123** to toggle between the numeric keyboard and the character keyboard
- the white up-arrow to toggle between lowercase and uppercase characters
- the blue up-arrow to create an uppercase character at the beginning of a sentence.

To jump to the start or the end of the message, touch the blue up-arrow or down-arrow by your message.

If you make a mistake, touch the red button to delete the last character (repeat if necessary). Alternatively, just touch the incorrect word or number to move the cursor quickly to that area.

Touch the green button to cancel your message completely.

When you have finished your message, touch **Send** to send it immediately.

The message is stored in your Sent Message list. If you want to see this, or check the time it was sent, touch Sent on the 'Received Messages' screen (see section 5.3).



5.8 Show a Message Location

Note: This section assumes that the Route-To message is already displayed. (A form message can also be set up as a Route-To message.)

Touch **Show** to exit from Messages and display the map.


Message 6 of 8
Message received at 11:00 AM on 01/01/08
Hinckley Rd (A4600), Walsgrave on Sowe, Coventry, United Kingdom, CV2 2
#235
Back flat, thru white gate and up brick path
Jack Norman 215 6623
No electricity to house, main line confirmed ok by Transline. Electric box back of house above balcony
Back
Reply
Delete
Go
Show

The location specified in the Route-To message is pinpointed on the map.

Choose one of the navigation options shown (then see section 7) or touch **Back** or **Close** to return to navigation.

5.9 Go to a Message Location

Note: This section assumes that the Route-To message is already displayed. (A form message can also be set up as a Route-To message.)

Touch Go to exit from Messages and navigate to the location specified in the Route-To message.


Message 2 of 12
Message received at 10:13 AM on 07/04/09
Jack Christie Dr, Hillsborough, Auckland, New Zealand, 1042
#235
Back flat, thru white gate and up brick path
Jack Norman 215 6623
No electricity to house, main line confirmed ok by Transline. Electric box back of house above balcony
Back
Reply
Delete
Go
Show

The M-Nav 760 immediately calculates the new route starting from your current location, then displays the navigation map and starts to give verbal directions.

5.10 Delete a Message

Note: This section assumes that the message you want to delete is already displayed.

Touch **Delete**. The 'Confirm Message Delete' box is displayed on the screen immediately.

Touch **Yes** to delete the message immediately. The updated Message List is displayed.

Note: The OnlineAVL2 application records the time that the message was deleted.



6 Phone

After pairing a Bluetooth-enabled mobile phone with your M-Nav 760, you can use the **Phone** option to make and receive mobile phone calls using the M-Nav as the hands-free device.

IMPORTANT: *The mobile phone must be compatible, be Bluetooth-enabled and Bluetooth must be ON (see the mobile phone manual if necessary).*

Note: You can pair more than one Bluetooth-enabled mobile phone with your M-Nav 760. However, you can have only **one** mobile phone actively connected at any one time (see section 6.4).

6.1 Check Bluetooth Status of the M-Nav 760

Display the 'Main Menu' or the 'Bluetooth Main Menu'.

Check the Bluetooth icon in the top right corner of the screen.

If you cannot see a Bluetooth icon, Bluetooth is OFF on your M-Nav 760. You must switch it ON (see section 6.2).

(Blue) Bluetooth is ON but is not connected with a mobile phone (see section 6.3).

(Green) Bluetooth is ON and connected with a mobile phone. You can make and receive mobile phone calls using the M-Nav 760 as the hands-free device.

6.2 Switch Bluetooth ON

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'.

Touch **Settings**.

The 'Settings' screen is displayed.

Touch the **OFF** button underneath Bluetooth.

Bluetooth turns ON.

Touch the back arrow in the top left corner to return to the 'Bluetooth Main Menu'.

The Bluetooth icon should now be visible in the top right corner of the screen.

(If it is blue, you need to pair a mobile phone with your M-Nav 760. See section 6.3).

6.3 Pair a Mobile Phone

The pairing process may vary slightly between different brands of mobile phone but the convenience of the easy-to-use M-Nav 760 Phone option makes it worthwhile.

IMPORTANT: *The mobile phone must be searchable (or in 'Listen' mode). See the mobile phone manual if necessary).*

Note: Bluetooth uses a universal frequency. Therefore, if you have a Bluetooth-enabled device already operating in the vehicle, this may cause interference when you try to pair your mobile phone with the M-Nav 760. If this happens, try removing the other device during the pairing process.

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'.

Touch **Connection** on the 'Bluetooth Main Menu'.

The 'Search Phone' screen is displayed.

Touch **Search**.

The M-Nav 760 searches for any Bluetooth-enabled devices close by.

The M-Nav 760 displays a list of Bluetooth-enabled devices that it has detected.

Touch the mobile phone that you want to pair with, e.g. **JAH Blackberry**.

The selected mobile phone is highlighted in orange.

Touch **Connect** to pair this mobile phone with your M-Nav 760.

The M-Nav 760 starts to pair with the mobile phone.

Check the mobile phone to see if it is asking you to enter a password. If so, enter **0000**.

Note: The mobile phone may also ask you to confirm whether the connection to the M-Nav 760 is allowed. If so, confirm that the connection is allowed.

The M-Nav 760 continues the pairing process with the mobile phone.

When the pairing process is complete, the 'Paired Record List' shows the mobile phone in orange.

Repeat the process if you want to pair another mobile phone with your M-Nav 760.

Note: You can pair more than one mobile phone to your M-Nav 760 but you can have only one mobile phone actively connected to your M-Nav 760 at any one time. The active phone is highlighted in orange.

6.4 Change the Active Mobile Phone

Note: Use this option when you have paired more than one mobile phone to your M-Nav 760 and want to change the active mobile phone.

IMPORTANT: *The mobile phone must be searchable (or in 'Listen' mode). See the mobile phone manual if necessary.*

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'.

Touch **Connection** on the 'Bluetooth Main Menu'.

The 'Paired Record List' is displayed.

The current active phone is highlighted in orange.

Touch the mobile phone that you want to select as the new active mobile phone. It is highlighted in orange.

Touch **Connect**.

The M-Nav 760 pairs with the mobile phone.

Check the mobile phone to see if it is asking you to enter a password. If so, enter **0000**.

Note: The mobile phone may ask you to confirm whether the connection to the M-Nav 760 is allowed. If so, confirm that the connection is allowed.



The M-Nav 760 continues the pairing process with the mobile phone.

When the pairing process is complete, the 'Paired Record List' shows the active mobile phone in orange.

6.5 Import a Phone Book

You can import and store the phone book from the actively connected mobile phone. The phone book is stored until you delete that mobile phone or change to a different active mobile phone.

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'.

Press **Contacts**.

The 'Phone Book' screen is displayed. Press **Import**.

A confirmation screen is displayed. Touch **OK**.

Note: The mobile phone may ask you to confirm whether the connection to the M-Nav 760 is allowed. If so, confirm that the connection is allowed.

The M-Nav 760 imports the phone book.

6.6 Make a Speaker Phone Call from Dial Pad

Note: This section assumes that you have paired a Bluetooth-enabled mobile phone with the M-Nav 760 and that this mobile phone is selected as the active mobile phone.

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'

Touch **Call-out** on the 'Bluetooth Main Menu'.

The dial pad is shown.

Enter the number that you want to call.

The phone icon is shown in blue.

Press the blue phone icon to make the call.

The call is placed.

The speaker icon shows that the M-Nav 760 is being used automatically as the speaker device.

Press the red phone icon to end the call.

Note: You can use the other M-Nav 760 functions (e.g. **Nav.**) while you are making the call.

The red phone icon and the mute icon are displayed on the screen so that you can end or mute the call at any time.

6.7 Make a Speaker Phone Call from Phone Book

Note: *This section assumes that you have paired a Bluetooth-enabled mobile phone with the M-Nav 760, this mobile phone is the active mobile phone and you have imported the mobile phone book.*

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'

Touch **Call-out** on the 'Bluetooth Main Menu'.

The dial pad is shown. Touch **Phone Book**.

The 'Phone Book' list is displayed. Use the up-arrow and down-arrow to scroll through the listing, is necessary.

Touch the number that you want to call. It is highlighted in orange.

The phone icon is shown in blue.

Press the blue phone icon to make the call.

The call is placed.

The speaker icon shows that the M-Nav is being used automatically as the speaker device.

Press the red phone icon to end the call.

6.8 Delete a Mobile Phone

Use this option to permanently delete a mobile phone from your M-Nav 760. If you imported the phone book, this will also be deleted from the M-Nav 760.

Note: You may also need to delete the M-Nav 760 from the mobile phone.

From the 'Main Menu', touch **Phone** to display the 'Bluetooth Main Menu'.

Touch **Connection** on the 'Bluetooth Main Menu'.

The 'Paired Record List' is displayed.

(If more than one mobile phone is listed, just touch the mobile phone that you want to delete. The selected mobile phone is highlighted in orange.)

Touch **Delete**.

The mobile phone is immediately deleted and removed from the 'Paired Record List'.

Note: If you imported the phone book, this is also automatically deleted from the M-Nav 760.

7 Navigation Basics

7.1 Display & Move the Map

Display the 'Main Menu'.

Touch **Nav**. to display the map.

Drag your finger across the screen to move the map in the same direction.

Note: To exit from the Navigation option at any time, touch **Menu** then **Main Menu**.

7.2 Map Icons

Use the map icons to see information and change the appearance of the map to suit your own preferences.

Note: After a time, the icons become transparent so that you can see more of the map but they are still active. When you touch the screen, the icons are shown in solid colour again.

Map Icon	Description
Menu	Navigation menu.
Route	Route menu.
30 m	Map scale.
	Temporarily increase the volume of the verbal navigation directions, one step at a time. (To change the volume of a phone call, use the Bluetooth volume control.)
	Volume muted.
	Zoom out to see less detail.
	Zoom in to see more detail.
	Decrease your elevation to show a landscape view of the map.
	Increase your elevation to show an aerial view of the map.
	The red compass arrow points North.
	Rotate the map clockwise.
	Rotate the map counter-clockwise.
	Battery status.

7.3 Navigation Icons

The route map has some special icons that help you navigate along the route and manage your schedule.

Note: After a time, the icons become transparent so that you can see more of the map, but they are still active. When you touch the screen, the icons are shown in solid colour again.

Navigation Icon	Description
	Marks the location that you touched and displays the navigation menu. Touch the map again to remove the icon OR choose an option from the navigation menu.
	A mini-map that shows an enlarged view of your next manoeuvre and the distance to it. Touch the icon in the upper left corner to hide or show the mini-map.
	DTG - Distance To Go to the next via point.
	ETA - Estimated Time of Arrival at the next via point.
	TTG – approximate Time To Go to the next via point.
	Local time (touch to toggle to the vehicle speed).
	Vehicle speed (touch to toggle to local time).
	Your present position. The arrow shows the direction that you are travelling. The name of the **current road** is shown in the menu bar at the bottom of the screen. The name of the **next road** is shown at the top of the screen.
	Your start location.
	After the route has been calculated, the green flags show the via points along your route. The via points are numbered in sequence along the route. This example shows the first via point.
	The calculated route is shown by a thick blue line and the blue direction arrows along the roads.
	A place that has been chosen as a via point. When the route is calculated, a thick blue line appears along the road and links all the via points to show the complete route.
	Your final destination.
	A favourite place.
	Centre-on-me (shown only when the M-Nav 760 has a GPS signal).

Navigation Icon	Description
	Touch this to show your route pointing to the top of the screen. The map display will turn to match your road view ahead.
	Touch this to show North at the top of the screen. The map display will NOT turn to follow your route.

7.4 Mute or Set the Navigation Volume

You can set then save the volume of the verbal navigation directions at a specific level, or mute it.

Display the 'Main Menu'.

Touch **Nav**. to display the map.

Touch **Menu**.

Touch the down-arrow to scroll through the listing then touch **Settings** to display the 'Settings' menu.

Touch **Volume** to display the 'Volume' settings.



Touch the blue slider and move it left to decrease the volume or right to increase the volume.

Note: If you move the blue slider into the red sector this provides an extra boost to the volume if it is not loud enough. This can be very useful if your vehicle is noisy, but can produce some distortion.

You can also touch the Mute icon to toggle this option ON or OFF.

7.5 Night-Time Navigation

If you are driving at night, you can show the map in night vision mode.

Note: We recommend that you use the **Auto day/night** option to automatically switch the map between day mode and night vision mode at dawn and dusk. Dawn and dusk are estimated automatically by your M-Nav 760.

To show the map in night vision mode, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu**.

Touch the down-arrow to scroll through the listing then touch **Settings** to display the 'Settings' menu.

Touch **Map**.

The 'Map' screen is displayed with the current map scheme setting.

Touch the current setting (e.g. **Auto day/night**).

The 'Map scheme' menu is displayed. Touch **Night**.

Touch **Close** to re-display the map in night vision mode.

7.6 How to Enter Data & Remove Errors

WARNING: Do **NOT** enter data while you are driving.

When you need to enter data such as a street address, the onscreen keyboard is displayed automatically.

You can toggle the onscreen keyboard between numbers OR characters, whenever you want, by touching **123** (or **ABC**) in the lower right corner. Touch the large white arrow in the blue box if you want to toggle between lowercase and uppercase characters.

If you make a mistake, you can touch the white arrow in the red box to delete the most recent character.

To remove the complete entry, drag your finger from the end to the start of the entry to highlight it all in blue, and then touch the white arrow in the red box to delete it so that you can start again.

8 Find and Go to a Location

8.1 Find a Street Address

To find a street address, display the 'Main Menu'.

Touch **Nav** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch **Find location**.

On the 'Find address' menu, touch **Find Address**.



Enter the street name, and the suburb or city, into the address box using the onscreen keyboard.

Note: If the previous entry is highlighted in blue in the address box, just touch the white arrow in the red box to clear it; then enter the new destination.

Touch **Find**.

The M-Nav searches for the street address and displays the results.

Sometimes there are multiple matches. If necessary, touch the down-arrow or up-arrow to scroll through the listing.

When you see the street address that you want, just touch it.

The street address that you touched is shown on the map with a list of options.

Touch **Navigate to** if you want the M-Nav 760 to calculate a route to that location.

If you want to add one or more via points along the route, see section 9.2. To learn more about the route before you start driving, see section 10.

8.2 Find a Postal Code

Note: This option may not operate in your region.

To find a postal code, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch **Find location** to display the Find address menu.

On the 'Find address' menu, touch **Find postal code**.



Enter the postal code using the onscreen keyboard then touch **Find**.

A list of matches is displayed. Touch the correct match.

The navigation map displays the postal code location and a list of options.

Touch **Navigate to** if you want the M-Nav 760 to calculate a route to that location.

If you want to add one or more via points along the route, see section 9.2.

To learn more about the route before you start driving, see section 10.



8.3 Find Other Types of Location

You can use the M-Nav 760 to find other types of location, such as an area.

Display the 'Main Menu'. Touch **Nav.** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch **Find location** to display the Find address menu.

Touch the type of location that you want to find (e.g. **Find Area**).



Enter the location information into the location box, as shown, using the onscreen keyboards.

Touch **Find**.

Note: if you are entering a Latitude and Longitude, use decimal degrees, e.g. 174.742621, -36.806738.

A list of matches is displayed (maximum of 99).

The matches are sorted by distance from your location or by alphabetic order. Touch **km** or **abc** to toggle between these sorting options.

When you see the location that you want, just touch it.



The location that you touched is shown on the map with a list of options.

Touch **Navigate to** if you want the M-Nav 760 to calculate a route to that location.

If you want to add one or more via points along the route, see section 9.2.

To learn more about the route before you start driving, see section 10.



8.4 Find a POI

To find a POI, display the 'Main Menu'.

Touch **Nav**. to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch **Find POI** to display the 'Place lookup' screen.

Use the onscreen keyboard to enter the POI name followed by a space and then suburb, town or city.

Note: If the previous entry is highlighted in blue in the address box, just touch the white arrow in the red box to clear it; then enter the new POI name.

Touch **Find**.

A list of matches is displayed.

Note: Sometimes there are multiple matches. If necessary, touch the down-arrow or up-arrow to scroll through the rest of the list.

When you see the location that you want, just touch it.



The navigation map displays the POI location and a list of options.

Choose an option from the menu if you want to add the place to your route (e.g. touch **Add a via point**).

Repeat this procedure if you want to show or add another place along the route.

8.5 Navigate to Destination from Your Location

WARNING: Set your destination while the vehicle is stationary.

To navigate from your present location to your destination, find and display the destination on the map (see the previous sections if necessary).

Touch **Navigate to**.

Note: Your M-Nav must be receiving a GPS signal so that it can calculate the route from your present location. See section 4.4 if necessary.

The M-Nav 760 immediately calculates a route from your present location, shows the route on the map, and starts to give verbal instructions.

Note: If you take a wrong turn, the M-Nav 760 will automatically re-calculate a new route to your destination. For safety reasons, the M-Nav 760 will not advise a U-turn unless this is the only option.

8.6 Set Location as Home

Note: When you have set a home location, a new menu option called 'Take me home' appears automatically at the top of the 'Navigation main menu'.

To set your home location, display the 'Main Menu'.

Touch **Nav**. to display the map.

Touch **Menu** to display the 'Navigation main menu'.

You can either:

- find the location and display it on the map (see sections 8.1 to 8.3 if necessary)
- or, if you have visited the location recently, touch **My recent destinations**. Touch the location that you want to set as home. It is displayed on the map.

Touch **More**.

Select **Set as Home**.

A message confirms that the location has been saved as your home location.

Your home location is shown in your list of favourite places, and identified as HOME.



Note: You can have only one home location. If you have already set a home location, a message asks you to confirm the new location as the home location.

8.7 Set a Location as a Favourite Place

To set a location as a favourite place, display the 'Main Menu'.



Touch **Nav**. to display the map.

Touch **Menu** to display the 'Navigation main menu'.

You can either:

- find the location and display it on the map (see section 8.1 if necessary) or
- if you have visited the location recently, touch **My recent destinations**. Touch the location that you want to make a favourite. It is displayed on the map.

Touch **More**.

Select **Add to Favourites**.

The onscreen keyboard is displayed. Enter the name of this favourite location (e.g. **Head Office**).

Touch **OK**.

A message confirms that the location has been saved to your list of favourite places.

To show a list of your favourite places, touch **Menu** then touch **My Favourite Places**.



Note: You can have a maximum of 99 saved Favourites and a maximum of 99 Recent Destinations.

9 Plan a Route

WARNING: Plan and edit your route while your vehicle is stationary.

A route can start from your present location or from any other location that you specify. As soon as you enter the destination, the M-Nav 760 will calculate the route for you.

When the route is calculated, you can:

- add or remove via points
- add or remove POIs
- change their order on the route.

If you will use this route regularly, you can save it.

You can also find out more about the route before you start your journey (see section 10).

9.1 Plan a Route from Any Location

You can plan a route in advance with the M-Nav 760.

To plan a route that does not start from your present location, find and display the starting location on the map (see sections 8.1 to 8.4 if necessary).

If the menu is not already displayed, touch **Menu**.

Touch **Set as Start**.

The location is immediately set as the start point and marked with a blue flag.

Touch **Menu**.

Find and display the destination on the map (see sections 8.1 to 8.4 if necessary).

Touch **Add a destination**.

The location is set as the destination and marked with a chequered flag, and the route is calculated immediately and shown on the map.

To add via points, see the following section.

To see information about the planned route, see section 10.

9.2 Add a Location as a Via Point

Note: This section assumes that the M-Nav 760 is showing your current route on the map.

When the M-Nav 760 has calculated a route, you can add one or more locations as via points to visit along the route or to detour to.

To add a location as a via point, touch **Menu** to display the 'Navigation main menu'.

Touch **Find location**.

Find and display the location of the first via point (see sections 8.1 to 8.4 if necessary) that you need to visit.

Note: The blue line shows the existing route.

Touch **Add a via point**.

The location is immediately added as a via point and the route is amended to include this new location.

Repeat this procedure to add another via point.

If you need to show or re-order the via points, see section 9.4.

9.3 Show / Add Places Along the Route

Note: This section assumes that the M-Nav 760 is showing your current route on the map.

When the M-Nav 760 has calculated a route, you can search for useful places along the route, such as hotels or banks.

To search for places along the route, touch **Route**.

The 'Trip' menu is displayed.

Touch **Places along the trip**.

The 'Select place category' screen is displayed.

Use the down-arrow and up-arrow to scroll to the correct category, if necessary.

Touch the category (e.g. **Parking**).

The M-Nav 760 immediately searches for places in that category then displays a list of results with their distances from the route.

The total number of results is shown at the bottom of the screen.

Use the up-arrow and down-arrow to see the complete listing, if necessary.


1. Carpark 150 m
Pearn Cres, Auckland (Hillcrest), North Shore...
2. Fredeo Motors 7.1 km
17 Union St, Auckland (Auckland Central),...
3. Aotea Square 7.6 km
Queen St, Auckland (Auckland Central),...
4. European Moters 8.3 km
East St, Auckland (Newton), Auckland City, New...
5. Carpark 12 km
Brixton Rd, Auckland (Balmoral), Auckland City,...
Search results (5)
Close
Back

Touch a place if you want to show it on the map.

Choose an option from the menu if you want to add the place to your route (e.g. touch **Add a via point**).

Repeat this procedure if you want to show or add another place along the route.



9.4 Optimise / Change the Order of the Via Points

Note: This section assumes that the M-Nav 760 is showing your current route on the map.

When the M-Nav 760 has calculated a route, you can show a list of all the via points and optimise their order, if necessary, to make your route more efficient.

To show the list of via points in the route and / or optimise their order, touch **Route**.

The 'Trip' menu is displayed. Touch **Via points list**.

The total number of via points is shown along the bottom of the screen.

The most recent via point that you added is shown at the top of the list, but the list may not show the most efficient order in which to visit the via points.

To re-order the via points, you can either:

- touch any via point to display a list of choices, then touch **Optimise stops order** OR
- touch the up-arrow or down-arrow in the red boxes by a particular via point to move it to an earlier or later position along the route.

The via points are immediately re-ordered and the route is re-calculated.



9.5 Save a Route

Note: This section assumes that the M-Nav 760 is showing your current route on the map.

Touch **Route** to show the 'Trip' menu.

Touch the down-arrow to scroll through the listing then touch **Save this trip**.

A message confirms that the route has been saved: 'Trip has been saved to My Trips'.

9.6 Add a Detour to Avoid an Area

WARNING: Add a detour while the vehicle is stationary.

Note: This section assumes that the M-Nav 760 is showing your current route on the map.

To calculate a detour (e.g. to avoid extensive road works), touch **Route** to show the 'Route' menu. Touch the down-arrow to scroll through the listing then touch **Avoid next**.



Touch the length of the detour that you want to take.

The M-Nav immediately calculates a detour for the specified distance and displays it on the map.

9.7 Use a Saved Route

To use a saved route, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu**.

Touch the down-arrow to scroll through the listing then touch '**My saved routes**'.

A list of your saved routes is displayed.

Touch the route you want to use.

1. 79 Queen St,
Auckland Central, Auckland, Auckland City, New...
Kawana St,
Northcote Point, Auckland, North Shore City, New...
2. Auckland University Of Technology,
Akoranga Dr, Northcote, Auckland, North Shore...
Auckland University Of Technology,
Great South Rd, Penrose, Auckland, Auckland City,...
Back
My saved routes (2)
Close

A map of the saved route is displayed with a list of options.

Touch **Load**. The route is immediately set as the current route.

If you are in your vehicle and ready to go, touch **Drive this trip** and navigation will start from your current location.



9.8 Delete a Saved Route

To save or delete a route, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch the down-arrow to scroll through the listing then touch '**My saved routes**'.

A list of your saved routes is displayed.

Touch the route you want to delete.

1. 79 Queen St,
Auckland Central, Auckland, Auckland City, New...
Kawana St,
Northcote Point, Auckland, North Shore City, New...
2. Auckland University Of Technology,
Akoranga Dr, Northcote, Auckland, North Shore...
Auckland University Of Technology,
Great South Rd, Penrose, Auckland, Auckland City,...
Back
My saved routes (2)
Close

A map of the route is displayed with a list of options.

Touch **Delete this trip**.

A message asks you to confirm that you want to delete the route. Touch **Yes** to confirm.

The route is immediately deleted and an updated list of your saved routes is displayed.



9.9 Delete a Route

Note: This section assumes that the M-Nav 760 is showing your current route on the map and that you have **not** saved the route.

Touch **Route** to show the 'Route' menu.

Touch the down-arrow to scroll through the listing then touch **Delete this route**.



A message is displayed, asking you to confirm that you want to delete the route.

Touch **Yes** to confirm.

The map is immediately re-displayed and the route is erased from it.



10 Route Information

You can check some information about the route before you start driving. You can:

- show a map overview of the complete route
- watch a demonstration of the route
- show the estimated travel time and distance
- show all the manoeuvres along the route.

10.1 Show an Overview of this Route

Note: This section assumes that the M-Nav 760 has calculated the route and is showing it on the map.

Touch **Route**. The 'Trip' menu is displayed.

Touch **Trip Overview**.



A map of the complete route, with any via points, is displayed.

Zoom in to see more detail, if necessary.

10.2 Demonstrate this Route

Note: This section assumes that the M-Nav 760 has calculated the route and is showing it on the map.

If you want the M-Nav 760 talk you through a demonstration of the route before you start driving, touch **Route**.

The 'Trip' menu is displayed. Use the down-arrow to scroll through the menu then touch **Demonstrate**.

The M-Nav 760 immediately starts to talk you through the route as though you were driving along it at high speed.

Touch **Route** then **Stop Demonstration** at any time to stop the demonstration.

Note: This option is available only when the M-Nav 760 cannot receive a GPS fix, e.g. when your vehicle is inside a building.

10.3 Show Total Time & Distance

Note: This section assumes that the M-Nav 760 has calculated the route and is showing it on the map.

Touch **Route**. The 'Trip' menu is displayed.

Touch **Trip Summary**.

The start and destination locations, the total distance, and the estimated time are immediately displayed.



10.4 Show all Manoeuvres on the Route

Note: This section assumes that the M-Nav 760 has calculated the route and is showing it on the map.

Touch **Route**. The 'Trip' menu is displayed.

Touch **Manoeuvres list**.

A preview of all the manoeuvres along the route is shown in sequence, two at a time, starting at the beginning of the route.

The total number of manoeuvres is shown at the bottom of the screen. Use the down-arrow and up-arrow to show more manoeuvres.

The number in the lower right corner of each manoeuvre shows its sequence number. This example shows the 7th and 8th manoeuvres along the route.



11 Set Your Preferences

You can specify the type of vehicle that you are driving. If you are driving a truck, you can specify some truck attributes such as the height of your truck.

Note: The 'Truck Attributes' option may not be available in your market. Contact your supplier for more information.

You can also define some route preferences, such as the types of road you want to exclude because they are unsuitable for your type of vehicle. The M-Nav 760 will then calculate all your routes based on these preferences. If you are driving a truck and have specified your truck attributes, the M-Nav will also use this information when calculating the routes.

You can also setup the date format, time format, and language shown on the M-Nav 760 to suit your own preferences.

11.1 Set Route Type & Vehicle Type

The M-Nav 760 can calculate your routes in three different ways, depending on your choice:

- **Fastest route** This uses motorways, when possible
- **Shortest route** The shortest distance
- **Optimal route** This balances speed and distance

You can also set your vehicle type.

Note: This section assumes that no current route is displayed on your M-Nav 760.

To set the route type or vehicle type, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Route** to display the 'Trip' menu.

Touch the down-arrow to scroll through the listing then touch **Route & vehicle types**.



The 'Route & vehicle types' screen displays the current settings.

To change the current route type, touch the Route type setting (e.g. **Fastest**).

The 'Route type' menu is displayed. The red circle shows the current setting.

Touch the route type that you want to use (e.g. **Shortest**).

The route type is immediately updated and the 'Route & vehicle types' screen is re-displayed with the new setting.

To change the current vehicle type, touch the Vehicle type setting (e.g. **Passenger**).

The 'Vehicle type' menu is displayed. The red circle shows the current setting.

Touch your vehicle type (e.g. **Truck**).

The vehicle type is immediately updated and the 'Route & vehicle types' screen is re-displayed.

Note: You need to set your vehicle type to '**Truck**' in order to set the Truck Attributes.

11.2 Set Truck Attributes

If you are driving a truck, you can specify some information about your truck, load and cargo. This information will be used by the M-Nav 760 when calculating the routes.

Note: This option may not be available in your market. Contact your supplier for more information.

Display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Route** to display the 'Route' menu.

Touch the down-arrow to scroll through the listing then touch **Truck Attributes**.



The 'Truck Attributes' menu displays a list of items that you can specify.

To specify the truck dimensions, touch **Dimensions**.



This 'Dimensions' screen is displayed.

Use the blue sliders to specify any or all of the details shown. Touch a blue slider and move it along the bar to change the existing setting.

When you have finished, touch either **Back** to specify more truck attributes, or **Close** to save the settings automatically and re-display the map.



To specify the load details, touch **Load**.

The 'Load' screen is displayed.

Use the blue sliders to specify any or all of the details shown. Touch a blue slider and move it along the bar to change the existing setting.

When you have finished, touch either **Back** to specify more truck attributes, or **Close** to save the settings automatically and re-display the map.

To specify the truck type or the type of cargo, touch **Truck & Cargo Types**.

The 'Truck & Cargo Types' menu is displayed with the current settings.

Touch the setting that you want to change. A list of choices is displayed.

Note: Different road restrictions may apply to different types of truck. Please check your regulations to ensure compliance, as any road restrictions added after the release of the M-Nav 760 are not included in the database.

This example shows the list of cargo types. A red circle identifies the cargo type that is selected.

Touch a cargo type to change the current setting.

When you have finished, touch **Back** to specify more truck attributes, or **Close** to save the settings automatically and re-display the map.

11.3 Set Road Types to Avoid

WARNING: The M-Nav 760 can calculate a route that avoids certain types of road that you specify (e.g. toll roads) unless there is no alternative route. In this case, the route will use these road types but will **not** advise you of this.

If you **must** avoid certain types of road, you must **exclude** them (see the next section).

Note: This section assumes that no current route is displayed on your M-Nav 760.

Display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Route** to display the 'Route' menu.

Touch the down-arrow to scroll through the listing then touch **Avoid Road types**.



The 'Avoid road types' menu displays a list of road types. A red circle identifies a road type that is avoided.

You can select more than one road type to avoid (or none at all).

Touch a road type to change the current setting.

11.4 Set Road Types to Exclude

The M-Nav 760 can calculate your routes so that they always exclude certain types of road that you specify (e.g. unpaved roads).

Note: If there is no alternative road type, the M-Nav 760 will not be able to calculate a route.

Note: This section assumes that no current route is displayed on your M-Nav 760.

Display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Route** to display the 'Trip' menu.

Touch **Exclude Road types.**



The 'Exclude road types' menu displays a list of road types. A red circle identifies a road type that is excluded.

Touch a road type to change the current setting.

11.5 Set Distance Units

To set the distance units, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch the down-arrow to scroll through the listing then touch **Settings** to display the 'Settings' menu.

Touch the down-arrow to scroll through the listing then touch **Units**.

The 'Units' screen is displayed with the current distance units.

Touch the current distance units (e.g. **Metric – kilometres**).



The 'Distance units' menu is displayed.

Touch the distance units that you want to use.

The 'Units' screen is re-displayed immediately with the new distance units.



11.6 Set Date / Time Formats

To set the date format, display the 'Main Menu'.

Touch **Settings** to display the 'Settings' menu.

Touch **Units**.

The 'Units' menu is displayed with the current date format and time format.



To change the date format, touch **Date Format**.

The 'Date Format' menu is displayed. The red circle shows the current setting.

Touch the new date format that you want to use (e.g. **dd/mm/yy**).

The date format is immediately updated and the 'Units' menu is re-displayed.

To change the time format, touch **Time Format**.

The 'Time Format' menu is displayed. The red circle shows the current setting.

Touch the new time format that you want to use (e.g. **24 hr**).

The time format is immediately updated and the 'Units' menu is re-displayed.



11.7 Set Geographic / Custom Time Zone

You can set either:

- a geographic time zone that automatically shows the local time, offset from GMT, at that location OR
- a custom time zone that enables you to offset your local time from GMT at 15 minute increments.

You must use either a geographic time zone OR a custom time zone. You cannot use both.

To set the geographic time zone or a custom time, display the 'Main Menu'.

Touch **Nav.** to display the map.

Touch **Menu** to display the 'Navigation main menu'.

Touch the down-arrow to scroll through the listing then touch **Settings** to display the 'Settings' menu.

Touch the down-arrow to scroll through the listing then touch **Time Settings**.

The 'Time settings' screen is displayed. This example shows the geographic time zone is set to GMT+12 based on an Auckland / Wellington location with the custom time zone option OFF.

Option ON

Option OFF

To change the geographic time zone, the 'Use custom time zones' option must be OFF.

Touch the current time zone setting (e.g. **GMT+12:00**).

A list of geographic time zones is displayed. Use the up-arrow or down-arrow to find the one you want to use, then touch it.

The 'Time settings' screen is re-displayed immediately with the new geographic time zone.



To use a custom time zone, the 'Use custom time zones' option must be ON.

Touch the current time zone setting (e.g. **GMT+12:00**).

A list of time offsets is displayed.

Use the up-arrow or down-arrow to find the time offset you want to use, then touch it.

The 'Time settings' screen is re-displayed immediately with the new custom time zone.

11.8 Set Language

The M-Nav 760 can operate in a variety of languages.

To set the language, display the 'Main Menu'.

Touch **Settings** to display the 'Settings' menu.

Touch **System**.



The 'System' menu is displayed with the current language shown.

Touch **Language**.



The 'Language' menu is displayed with the current language highlighted.

Use the up-arrow and down-arrow to scroll through the listing to find the language you want to use, then touch that language.

The language is immediately updated and the 'System' menu is re-displayed with the new language selection.

11.9 Set the Choose Language at Startup Option

You can choose whether or not to show the 'Language' selection menu (described in the previous section) whenever you switch on the M-Nav 760.

To change the current 'Choose Language at Startup' setting, display the 'Main Menu'.

Touch **Settings** to display the 'Settings' menu.

Touch **System**.

The 'System' screen is displayed.

Use the up-arrow and down-arrow to scroll through the listing then touch **Choose Language at Startup.**



The 'Choose Language at Startup' screen is displayed with the current setting highlighted.

Touch the new setting that you want to use (e.g. **Off**).

The setting is immediately updated and the 'System' menu is re-displayed with the new setting.



11.10 Restore Factory Default Settings

In the unlikely case of any problems with your M-Nav 760 that you cannot otherwise resolve, you can restore the factory default settings.

WARNING: This option will remove all of your customised settings and stored information except your map selection.

To restore your M-Nav 760 to the factory default settings, display the 'Main Menu'.

Touch **Settings** to display the 'Settings' menu.

Touch **System**.

The 'System' screen is displayed.

Use the up-arrow and down-arrow to scroll through the listing then touch **Saved Info**.



The 'Saved Info' screen is displayed.

Touch the **Restore Factory Defaults.**



A message asks you to confirm that you want to restore the factory default settings.

Touch **Yes** to confirm.

All of the M-Nav 760 settings (except for the map selection) are immediately reset to the factory default settings.



Contact Information

Navman Wireless welcomes your feedback.

Navman Wireless UK
Innovation Centre 2,
Keele University Science Park
Keele, Newcastle Under Lyme
Staffordshire, ST5 5NH
UNITED KINGDOM
Tel: +44 (0) 1782 55 79 50
Fax: +44 (0) 1782 55 79 79
Email: support@navmanwireless.co.uk
Website: www.navmanwireless.co.uk

Navman Wireless USA
Navman Wireless North America
2701 Patriot Boulevard, Suite 150
Glenview, IL 60026
USA
Tel: +1 (866) 527 9896
Fax: +1 (847) 729 5988
Email: us.support@navmanwireless.com
Website: www.navmanwirelessus.com

Navman Wireless Australia Pty
Unit 3, 2-6 Chaplin Drive
Lane Cove, NSW 2066
PO Box 3051, Monash Park NSW 2111
Sydney, AUSTRALIA
Website: www.navmanwireless.com.au

Navman Wireless NZ
Navman New Zealand
7-11 Kawana Street, Northcote
PO Box 340-184, Birkenhead 0746
Auckland, NEW ZEALAND
Website: www.navmanwireless.co.nz

Navman Wireless Italy
Via Martiri Soncinesi 3
Soncino CR 26029
Italia
Tel: +39 0374 84140

Navman Wireless Scandinavia
Kometvej 10
DK-6230
Rødekro
Danmark
Tel: Danmark: +45 70 269 732
Tel: Sweden: +46 8 559 21 916
Tel: Finland: +35 89 2316 3595

Navman Wireless Mexico
Calzada San Pedro #100
Col. del Valle, San Pedro Garza Garcia
Nuevo Leon. CP 66220
Mexico
Tel: +52 (81) 8248 4600 Extn 1001
Email: soporte@navmanwireless.com

Navman Wireless Taiwan
#3, 25Fl., No.508, Sec.5 Zhongxiao E. Rd.,
Xinyi Dist., Taipei 110,
11083
Taiwan
Tel: +886 (0)2 2728 2818
Fax: +886 (0)2 2728 2816

MAN000004 Rev B

NAVMAN WIRELESS